

RoscoLED[®] Tape Profile

Installation Instructions



- 1. Profile without mounting clips:** Drill holes on one-foot centers and attach with screws (not included).

Profile with mounting clips: Attach mounting clips to surface on one-foot centers with screws (not included). Snap aluminum profile into clips.

Note: Align profiles end-to-end if installing multiple profiles for longer runs.

- 2. Clean the interior aluminum area of the Profile using Isopropyl Alcohol.**
Allow to dry completely before installing RoscoLED Tape.

- 3. Remove protective film to expose the adhesive on the underside of RoscoLED Tape.**
Apply RoscoLED Tape to the Profile's inner channel using firm, even pressure.

- 4. Snap or slide lens into the Profile.**
Install Profile end caps.

- 5. Apply clear silicone (not included) sealant at end caps or Profile joints to minimize dust ingress.**

- 6. Remove protective film from lens cover after installing.**

